

FIG. 1




FIG. 2

Initialize Configuration ~ 200

eth1 pinging target IP address ~ 210

eth1 goes down ~ 240
No
AT MAX
NO. OF
RETRIES

can it reach the target? ~ 270
Yes
OR NO UNTIL
MAX NO. OF
RETRIES

PINGING
STOPS
TEMPORARILY ~ 230

PPP comes up,
sends route
update to remote
peer
GOTO FIG. 3 ~ 250

FAILOVER
ENABLED? ~ 265
YES

PPP checks
target ~ 270

can it reach
target? ~ 280
Yes

PPP goes down ~ 300

eth1 comes up,
sends route
update to remote
peer ~ 310


PPP stay up, keep
checking target ~ 290

MAINTAIN
PPP
Connection ~ 267

FIG. 3

Step 250, FIG. 3

FIG. 4



GO TO STEP 270, FIG. 3